






	Description		For Use With	Cat. No.
	Legend Plate	Marking: "Hauptschalter" and "Main Switch"	140-CDN66	140M-C-DFCN
		Marking: "Not-Aus" and "Emergency Off"	140-CDRY66	140M-C-DFCRY
	IP65 Non-Metallic Enclosure <ul style="list-style-type: none"><li>• Knockouts for M20 and M25 fittings</li><li>• Suitable for flexible cable with internal ground wire or conduit when externally grounded around the outside of the enclosure (no UL/CSA approval)</li></ul>	Black Handle	140M-C	198E-AYTG2
		Red/Yellow Handle	140M-C	198E-AYTJ2
	Screw Adapter <ul style="list-style-type: none"><li>• For screw arrangement of a motor protection circuit breaker</li><li>• Must be ordered in multiples of 10 (10 pcs/pkg)</li></ul>		140M-C, D, F 140U- D	140M-C-N45

	Description	For Use With	Cat. No.
	ECO Connecting Module — 12 A • For DOL and reversing starters • Eco-starters mount on single DIN Rail (140M on DIN Rail) • Electrical and mechanical interconnection of 140M and 100-K contactors	140M-C to 100-K	140M-C-PEK12
	ECO Connecting Modules — 25 A • Eco-starters mount on single DIN Rail (140M on DIN Rail) • Electrical and mechanical interconnection of 140M MPCB and 100-C (with AC coils or 24V DC electronic coils) contactors	140M-C to 100-C09...C23	140M-C-PEC23
		140M-D to 100-C09...C23	140M-D-PEC23
	ECO Connecting Modules — 25 A • Eco-starters mount on single DIN Rail (100-C on DIN Rail) • Electrical and mechanical interconnection of 140M MPCB and 100-C (with conventional DC coils)	140M-C, 140M-D to 100-C09...C23	140M-C-PEC23A
	Connecting Modules — 25 and 45 A • Contactor and MPCB MUST BE mounted separately on (2) DIN Rails Electrical interconnection of 140M and 100-C (with AC coils)	140M-C to 100-C09...C23	140M-C-PNC23
		140M-D to 100-C09...C23	140M-D-PNC23
		140M-D to 100-C30...C37	140M-D-PNC37
		140M-F to 100-C30...C37	140M-F-PNC37
	Coil Modules — 25 A and 45 A • For use with Bulletin 103T/107T 3-component starters	140M-F to 100-C43	140M-F-PNC43
		140M-C, -D to 100-C09...C23	140M-C-PSC23
	Spacing Adapter • Required for self-protected combination motor controller (Type E) applications of Bul. 140M-C, -D, and -F MPCBs. Not for use with bus bars.	140M-C, -D	140M-C-TE1
		140M-F	140M-F-TE