

Accessories

Table 34 - Auxiliary Contacts

Description	Operator Position ⁽¹⁾			Term. No.	Contact Description	Connection Diagram ⁽²⁾	For Use With	Cat. No.
	OFF	ON	Tripped					
 Front-Mounted Auxiliary Contact 1-pole or 2-pole - No additional space required - Only one per device	0	X	0	13-14	N.O. Aux		140MT (all) 140UT-D	140MT-C-AFA10
	0	X	0	13-14	N.O. Aux		140MT (all) 140UT-D	140MT-C-AFA11
 Front-Mounted Auxiliary Contact 1-pole or 2-pole - No additional space required - Only one per device	X	0	X	21-22	N.C. Aux		140MT (all) 140UT-D	140MT-C-AFA11
	0	X	0	13-14	N.O. Aux		140MT (all) 140UT-D	140MT-C-AFA20
 Right Side-Mounted Auxiliary Contact 2-pole - Adds 9 mm (0.35 in.) to the width of the device - One per device - Not suitable for UL 489 applications	0	X	0	33-34	N.O. Aux		140MT (all) 140UT-D	140MT-C-ASA20
	0	X	0	43-44	N.O. Aux		140MT (all) 140UT-D	140MT-C-ASA20
 Right Side-Mounted Auxiliary Contact 2-pole - Adds 9 mm (0.35 in.) to the width of the device - One per device - Not suitable for UL 489 applications	X	0	X	31-32	N.C. Aux		140MT (all) 140UT-D	140MT-C-ASA02
	X	0	X	41-42	N.C. Aux		140MT (all) 140UT-D	140MT-C-ASA02
 Right Side-Mounted Auxiliary Contact 2-pole - Adds 9 mm (0.35 in.) to the width of the device - One per device - Not suitable for UL 489 applications	0	X	0	33-34	N.O. Aux		140MT (all) 140UT-D	140MT-C-ASA11
	X	0	X	41-42	N.C. Aux		140MT (all) 140UT-D	140MT-C-ASA11

(1) X = Contact Closed; 0 = Contact Open

(2) Connection Diagram Reference:

