SIEMENS

Data sheet

3RQ3052-1SM40



Output coupler Optocoupler 1 NO contact, Transistor Input 24 V DC Output max. 60 V DC, 2 A Overall width 6.2 mm screw terminal Thermal current 2A

product brand name	SIRIUS
product category	SIRIUS 3RQ3 coupling relays in slim design
product designation	Coupling relays with semiconductor output (not plug-in)
design of the product	Output coupling link
product type designation	3RQ3
General technical data	
display version LED	Yes
product component	
 relay output 	No
 semi-conductor output 	Yes
consumed active power	0.3 W
insulation voltage for overvoltage category III according to IEC 60664 with degree of pollution 3 rated value	50 V
surge voltage resistance rated value	2.5 kV
protection class IP	IP20
flammability class of enclosure material	UL94 V-0
shock resistance	
according to IEC 60068-2-27	sinusoidal half-wave 15g / 11 ms
vibration resistance	
according to IEC 60068-2-6	6 150 Hz: 2 g
switching frequency	30 Hz
thermal current	2 A
reference code according to IEC 81346-2	К
Substance Prohibitance (Date)	03/25/2015
Control circuit/ Control	
control supply voltage at DC	
rated value	11 30 V
operating range factor control supply voltage rated value at DC	
initial value	1
 full-scale value 	1
minimum switching voltage when switching on	11 V
maximum switching voltage when switching off	5 V
ON-delay time	
at DC maximum	0.3 ms
OFF-delay time	2 ms
product component plug-in socket	No
Auxiliary circuit	
type of switching contact	NO contact
number of NO contacts for auxiliary contacts	1
Main circuit	

tune of voltage	DC
type of voltage	DC
Inputs/ Outputs	
property of the output short-circuit proof	No
switching voltage of the semiconductor output at DC	10 60 V
ampacity of the semiconductor output at DC	1 mA 2 A
Electromagnetic compatibility	
EMC emitted interference according to IEC 60947-1	ambience A (industrial sector)
EMC immunity according to IEC 60947-1	corresponds to degree of severity 3
conducted interference	
• due to burst according to IEC 61000-4-4	2 kV
• due to conductor-earth surge according to IEC 61000-4-5	2 kV
 due to conductor-conductor surge according to IEC 61000-4-5 	1 kV
field-based interference according to IEC 61000-4-3	10 V/m
electrostatic discharge according to IEC 61000-4-2	6 kV contact discharge / 8 kV air discharge
Display	
display version as status display by LED	LED green
Connections/ Terminals	
product function removable terminal	No
type of electrical connection for auxiliary and control circuit	screw-type terminals
wire length	
• at DC maximum	1 000 m
type of connectable conductor cross-sections	
• solid	1x (0.25 2.5 mm²)
 finely stranded with core end processing 	1x (0.25 1.5 mm ²)
at AWG cables solid	1 x (20 14)
connectable conductor cross-section	
• solid	0.25 2.5 mm²
 finely stranded with core end processing 	0.25 1.5 mm²
AWG number as coded connectable conductor cross	
section	
• solid	20 14
tightening torque with screw-type terminals	20 14 0.5 0.6 N·m
tightening torque with screw-type terminals	
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method	0.5 0.6 N·m
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height	0.5 0.6 N·m any snap-on mounting 93 mm
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method	0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth	0.5 0.6 N·m any snap-on mounting 93 mm
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing	0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting	0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 72.5 mm
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting — forwards	0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 72.5 mm 0 mm
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting — forwards — backwards	0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 72.5 mm 0 mm 0 mm
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting — forwards — backwards — upwards	0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 72.5 mm 0 mm 0 mm 0 mm
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting — forwards — backwards — upwards — downwards	0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 72.5 mm 0 mm 0 mm 0 mm 0 mm
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side	0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 72.5 mm 0 mm 0 mm 0 mm
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting forwards backwards upwards downwards at the side • for grounded parts	0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 72.5 mm 0 mm
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting - forwards - backwards - upwards - downwards - at the side • for grounded parts - forwards - for	0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 72.5 mm 0 mm
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting forwards backwards upwards downwards at the side • for grounded parts forwards backwards	0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 72.5 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting - forwards - backwards - upwards - downwards - at the side • for grounded parts - forwards - backwards - upwards - up	0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 72.5 mm 0 mm
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting - forwards - backwards - backwards - upwards - at the side • for grounded parts - forwards - backwards - backwards - at the side -	0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 72.5 mm 0 mm
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting - forwards - backwards - upwards - downwards - at the side • for grounded parts - forwards - backwards - upwards - at the side - at	0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 72.5 mm 0 mm
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting - forwards - backwards - backwards - upwards - downwards - at the side • for grounded parts - forwards - upwards - at the side - downwards - at the side - at the side - at the side - at the side - at the	0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 72.5 mm 0 mm
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting - forwards - backwards - backwards - upwards - downwards - at the side • for grounded parts - forwards - backwards - upwards - at the side - downwards - at the side - downwards - at the side - downwards - for live parts - forwards - forwards - forwards - forwards - forwards - forwards - for live parts - forwards - for live parts - forwards - forwa	0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 72.5 mm 0 mm
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts — forwards — backwards — upwards — at the side — downwards — at the side — downwards — at the side — downwards • for live parts — forwards • for live parts — forwards — backwards — backwards — downwards • for live parts — forwards — backwards — backwards • for live parts — forwards — backwards — backwards • for live parts — forwards — backwards — backwards — backwards	0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 72.5 mm 0 mm
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting - forwards - backwards - backwards - upwards - downwards - at the side • for grounded parts - forwards - backwards - upwards - at the side - downwards - at the side - downwards • for live parts - forwards • for live parts - forwards - backwards - upwards - backwards - upwards - downwards - at the side - downwards - at the side - downwards - at the side - downwards - backwards - upwards - forwards - upwards - upwar	0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 72.5 mm 0 mm
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting - forwards - backwards - backwards - upwards - at the side • for grounded parts - forwards - at the side - downwards - at the side - downwards - at the side - for live parts - forwards - backwards - upwards - backwards - upwards - backwards - upwards - forwards - at the side - downwards - backwards - upwards - backwards - backwards - backwards - upwards - backwards	0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 72.5 mm 0 mm
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting - forwards - backwards - upwards - downwards - at the side • for grounded parts - forwards - backwards - upwards - at the side • for live parts - forwards - backwards - upwards - backwards - backwards - backwards - downwards - forwards - downwards - at the side • for live parts - forwards - backwards - upwards - backwards - upwards - backwards - backwar	0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 72.5 mm 0 mm
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting - forwards - backwards - backwards - upwards - at the side • for grounded parts - forwards - backwards - upwards - backwards - upwards - at the side • for live parts - forwards - backwards - upwards - backwards - upwards - backwards - downwards - at the side • for live parts - forwards - backwards - upwards - backwards - at the side - downwards - backwards - upwards - at the side - downwards - at the side - downwards - at the side - downwards - backwards - upwards - backwards - ba	0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 72.5 mm 0 mm
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting - forwards - backwards - upwards - downwards - at the side • for grounded parts - forwards - backwards - upwards - at the side • for live parts - forwards - backwards - upwards - backwards - backwards - backwards - downwards - forwards - downwards - at the side • for live parts - forwards - backwards - upwards - backwards - upwards - backwards - backwar	0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 72.5 mm 0 mm

 during operation 	-25 .	+60 °C						
 during storage 	-40 .	-40 +85 °C						
 during transport 	-40 .	-40 +85 °C						
relative humidity during operation	10	. 95 %						
Certificates/ approvals								
General Product Approval				EMC				
	<u>Confirmation</u>		EHC	RCM				
Declaration of Conformity	Test Certificates	Marine / Shipping	other					
UK CA CE EG-Konf.	Type Test Certific- ates/Test Report	DIVISION AND DIVISION	<u>Confirmation</u>					
Further information								
Siemens has decided to exit the Russia		and and the second second						
https://press.siemens.com/global/en/pressrelease/siemens-wind-down-russian-business Siemens is working on the renewal of the current EAC certificates. Please contact your local Siemens office on the status of validity of the EAC certification if you intend to import or offer to supply these products to an EAC relevant market (other than the sanctioned EAEU member states Russia or Belarus). Information on the packaging								
https://support.industry.siemens.com/cs/ww/en/view/109813875								
Information- and Downloadcenter (Catalogs, Brochures,) https://www.siemens.com/ic10								
Industry Mall (Online ordering system) https://mall.industry.siemens.com/mall/en/en/Catalog/product?mlfb=3RQ3052-1SM40								
https://mail.industry.siemens.com/mail/en/en/Catalog/product?mltb=3RQ3052-1SM40 Cax online generator								
http://support.automation.siemens.com/WW/CAXorder/default.aspx?lang=en&mlfb=3RQ3052-1SM40								
Service&Support (Manuals, Certificates, Characteristics, FAQs,) https://support.industry.siemens.com/cs/ww/en/ps/3RQ3052-1SM40								
Image database (product images, 2D dimension drawings, 3D models, device circuit diagrams, EPLAN macros,)								
http://www.automation.siemens.com/bilddl								
Characteristic: Derating	Characteristic: Derating							

Characteristic: Derating https://support.industry.siemens.com/cs/ww/en/ps/3RQ3052-1SM40/manual





last modified:

5/6/2021 🖸

3RQ30521SM40 Page 4/5

5/11/2023

Subject to change without notice © Copyright Siemens