

IEC Power Devices

Contactors Enclosures Accessories

C-2000

Section 5

Enclosure Accessories

Enclosure Accessory Type	For Use With	Product Number	List Price GO-10C2
Start-Stop Push Button Without Light	CL00, CL01, CL02, CL25, CL04, CL45 starters with or without CPT	CLXP1B	
Start-Stop Push Button Without Light	CL06, CL07, CL08 starters with or without CPT	CLXP2B	
Start-Stop Push Button Without Light	CL09, CL10 starters with or without CPT	CLXP3B	
Start/Stop Push Button With Light	CL00, CL01, CL02, CL25, CL04, CL45 starters with or without CPT	CLXP1C*	
Start/Stop Push Button With Light	CL06, CL07, CL08 starters with or without CPT	CLXP2C*	
Start/Stop Push Button With Light	CL09, CL10 starters with or without CPT	CLXP3C*	
H-O-A Switch	CL00, CL01, CL02, CL25, CL04, CL45 starters with or without CPT	CLXP1D	
H-O-A Switch	CL06, CL07, CL08 starters with or without CPT	CLXP2D	
H-O-A Switch	CL09, CL10 starters with or without CPT	CLXP3D	
On-off Switch	CL00, CL01, CL02, CL25, CL04, CL45 starters with or without CPT	CLXP1E	
On-off Switch	CL06, CL07, CL08 starters with or without CPT	CLXP2E	
On-off Switch	CL09, CL10 starters with or without CPT	CLXP3E	
Red Indicating Light	CL00, CL01, CL02, CL25, CL04, CL45 starters with or without CPT	CLXP1F	
Red Indicating Light	CL06, CL07, CL08 starters with or without CPT	CLXP2F	
Red Indicating Light	CL09, CL10 starters with or without CPT	CLXP3F	
Reset Kit	CL00-45 Starters with and without CPT, Type 1 (CLXE1A, 1D)	CLXR11	
Reset Kit	CL05-10 Starters, CL00-10 Reverser and Wye-Delta Type 1 (CLXE1B-1C, CLXE1E-1L)	CLXR12	
Reset Kit	CL00-10 Starters, Reverser and Wye-Delta Type 12/3R and 4 (CLXE2A-2H, CLXE4A-4H)	CLXR21	
Reset Kit	CK75-12 Starters, Reverser and Wye-Delta Type 1	CKXR11	
Reset Kit	CK75-12 Starter, Reverser and Wye-Delta Type 12/3R and 4	CKXR12	
Control Power Transformer (CPT)	Standard capacity (50 VA)	CR308XT1**A	
Control Power Transformer (CPT)	Extra capacity (150 VA)	CR308XT1**B	

Replace asterisk (*) in product number for Start/Stop Push Button With Light with appropriate voltage code.

Voltage Selection*

*Code	Voltage
1	115 Volts
2	230 Volts
4	460 Volts
5	575 Volts

**To complete product number, replace ** with the appropriate digits from below:

Control Power Transformer Voltage Selection**

Digit	Voltage	Frequency
04	Dual Primary Reconnectable 220/230/240 and 440/460/480 Volt Primary, 110/115/120 Volt Secondary	60 Hz
05	550/575/600 Volt Primary, 110/115/120 Volt Secondary	60 Hz
23	200/208 Volt Primary, 115/120 Volt Secondary	60 Hz

Reference Publications

Instructions

GEH-5521	Enclosures CLXE1G-CLXE1L
GEH-5522	NEMA 1 Lift-Off Enclosures
GEH-5523	CLXR11, 12 Reset Push Button
GEH-5524	CLXR21, CKXR11, 12 Reset Button
GEH-5525	CLXP-B, C Start/Stop Push Button
GEH-5526	CL NEMA 12/3R Enclosures
GEH-5527	CL NEMA 4 Enclosures



Start/Stop Push Button without Light




Start/Stop Push Button with Light



H-O-A Switch



On-Off Switch



Red Indicating Light



Reset Kit



Control Power Transformer



Product Number Selection Instructions: See page 5-37