


How To Order




Note 4) If foot bracket is required for a cylinder, order a pair

100


(N)CQ-L100 (N)CQ-F100 (N)CQ-D100

Note 5) Each bracket comes with the following accessories; Foot / Flange; Body mounting bolt Double clevis; Clevis pin, Axis C style snap ring, Body mounting bolt

Compact Cylinder: Standard / Double Acting Single Rod




Bore size (mm)	Stroke range (mm)	A	В	L	CQ2	NCQ2	LD	LG	LH	LS	LT	LX	LY	LZ	x	Y
12	5~30	35.3	17	13.5	24	21.5	4.5	2.8	17	5	2	34	29.5	44	8	4.5
16	5~30	36.8	18.5	13.5	25.5	21.5	4.5	2.8	19	6.5	2	38	33.5	48	8	5
20	5~50	41.2	19.5	14.5	28.5	22.5	6.6	4	24	7.5	3.2	48	42	62	9.2	5.8
25	5~50	44.7	22.5	15	32.5	24.5	6.6	4	26	7.5	3.2	52	46	66	10.7	5.8



Bore size (mm)	Stroke range (mm)	A	В	FD	FT	FV	FX	FZ	L	CQ2 L1	NCQ2
12	5~30	30.5	17	4.5	5.5	25	45	55	13.5	24	21.5
16	5~30	32	18.5	4.5	5.5	30	45	55	13.5	25.5	21.5
20	5~50	34	19.5	6.6	8	39	48	60	14.5	28.5	22.5
25	5~50	37.5	22.5	6.6	8	42	52	64	15	32.5	24.5






Head Side Flange / (N)CQ2G mm

Rod Side Flange / (N)CQ2F

30.00		21.000076	_		,
Bore size (mm)	Stroke range (mm)	A	L	CQ2	NCQ2
12	5~30	26	3.5	14	11.5
16	5~30	27.5	3.5	15.5	11.5
20	5~50	32	4.5	18.5	12.5
25	5~50	35.5	5	22.5	14.5

*Dimensions for the head flange cylinder are the same as rod flange except A, L, L1.



Double Clevis / (N)CQ2D

Bore size (mm)	Stroke range (mm)	A	В	CQ2 CD	NCQ2 inch CD	CL	СТ	cu	cw	сх	cz	L	CQ2 L1	NCQ2	CQ2 N	NCQ2 inch N	RR
12	5~30	40.5	17	5	3/16	34.5	4	7	14	5	10	3.5	14	11.5	M4x0.7	8-32	6
16	5~30	43	18.5	5	3/16	37	4	10	15	6.5	12	3.5	15.5	11.5	M4x0.7	8-32	6
20	5~50	51	19.5	8	5/16	42	5	12	18	8	16	4.5	18.5	12.5	M6x1.0	1/4-20	9
25	5~50	57.5	22.5	10	3/8	47.5	5	14	20	10	20	5	22.5	14.5	M6x1.0	1/4-20	10

[★] Rod end nut and accessories detail: see p. 6.

^{★ ★} Clevice pin and snap rings are included in the package.