



TruONE™ automatic transfer switch

Accessories



Auxiliary contacts		
Suitable for switches	Type	Ordering Code
OX30....1200	1-NO AUX SW OT/OS	OA1G10
OX30....1200	AUX SWITCH 1NC OS/OT	OA3G01



Terminal Lug kits						
Type	Wire Range	Wires per lug	2 lugs kit	3 lugs kit	4 lugs kit	6 lugs kit
OZXA-100	14-2/0 AWG	1			OZXA-100/4P	OZXA-100
OZXA-24	14-2/0 AWG	1	OZXA-24/2P	OZXA-24/3P	OZXA-24/4P	
OZXA-200	4 AWG - 300kcmil	1			OZXA-200/4	OZXA-200
OZXA-25	6 AWG - 300kcmil	1	OZXA-25/2P	OZXA-25/3P	OZXA-25/4P	
OZXA-400	2 AWG - 600kcmil	1			OZXA-400/4	OZXA-400
OZXA-26	2 AWG - 600kcmil	1	OZXA-26/2P	OZXA-26/3P	OZXA-26/4P	
OZXA-412	2 AWG - 600kcmil	1 or 2			OZXA-412/4P	OZXA-412
OZXA-412L	2 AWG - 600kcmil	1 or 2	OZXA-412L/2P	OZXA-412L/3P	OZXA-412L/4P	
OZXA-800E	2 AWG - 600kcmil	2			OZXA-800E/4P	OZXA-800E
OZXA-800S	2 AWG - 600kcmil	2			OZXA-800S/4P	OZXA-800S
OZXA-800LT	2 AWG - 600kcmil	2	OZXA-800LT/2	OZXA-800LT/3	OZXA-800LT/4	
OZXA-1200	2 AWG - 600kcmil	4			OZXA-1200/4	OZXA-1200

- (1) One complete kit contains enough pieces for both Source S2 and Load terminals.
- (2) Apply 2 pieces to Source S2 terminal of each pole.
- (3) One complete kit contains enough pieces for both Load and Source S1 terminals.