


Illuminated push-buttons


		Cat. no.	Ref. no. see bottom	Cat. no.	Ref. no. see bottom	Cat. no.	Ref. no. see bottom
		Metal		Plastic		Plastic	
							
Standard / Momentary							
	With diffused lens:						
	Flush	P9MPL●GD		P9XPL●GD		P9SPL●GD	
	Raised	P9MPL●SD		P9XPL●SD		P9SPL●SD	
	Recessed	P9MPL●ED					
Mushroom head / Momentary							
	Mushroom head Ø40 mm	P9MEM4●L		P9XEM4●L*			
	Mushroom head 30 mm					P9SEM3RL	186551
Mushroom head / With latch							
	Push-pull to release						
	Mushroom head Ø40 mm	P9MET4●L1		P9XET4●L1*		P9SET4RL1	186561
				* Color R, V or G			
Mushroom head / 3 positions							
	With mushroom Ø40 mm						
	1-0 fixed, 2 transient	P9MET4●L2		P9XET4RL2	185571		
	0 transient, 1-2 fixed	P9MET4●L3					



Illuminated selector switches with knob

2 positions		Function (1)				
	Fixed		D	P9MSLD0●	P9XSLD0●	P9SSLD0●
3 positions						
	Fixed		Z, B	P9MSLZ0●	P9XSLZ0●	P9SSLZ0●
			Z, B	P9MSLZ1●		
	With spring return		Z, B	P9MSLZ5●		
			Z, B	P9MSLZ3●		
			Z, B			

Illuminated selector switches with lever

2 positions		Function (1)				
	Fixed		D	P9MSAD0●		
3 positions						
	Fixed		Z, B	P9MSAZ0●		
			Z, B	P9MSAZ1●		
	With spring return		Z, B	P9MSAZ5●		
			Z, B	P9MSAZ3●		
			Z, B			

(1) Electrical diagrams, see E.22

The catalogue numbers **in bold** are available from stock.

Colours		red	green	yellow	orange	blue	white	clear
Lens	●	R	V	G	A	L	B	I
Mushroomheads	●	R	V	G	A	L	B	I
Knob/lever	●	R	V	G	A	L	B	I

For reference numbers, see chapter X, pg. X.8

