

Individual Parts

Switches without Levers, Heads, and Actuators

General-purpose Parts

Actuator	Item	Pretravel (PT)	Set	Switch without levers	Head *1 (with Actuators)	Actuator only *2
				Model	Model	Model
Roller lever 	Basic	15±5°	WLCA2-N	WLCA2-N	WL-1H1100-N	WL-1A100
		25±5°	WLCA2-2-N	WLCA2-2-N	WL-3H1100-N	
		MAX20°	WLCA2-2N-N	WLCA2-2N-N	WL-1H1100-N	
	High-sensitivity	10° $\pm \frac{2}{1}$	WLG2-N	WLG2-N	WL-2H1100-N	
Adjustable roller lever 	Basic	15±5°	WLCA12-N	WLCA12-N	WL-1H2100-N	WL-2A100
		25±5°	WLCA12-2-N	WLCA12-2-N	WL-3H2100-N	
		MAX20°	WLCA12-2N-N	WLCA12-2N-N	WL-1H2100-N	
	High-sensitivity	10° $\pm \frac{2}{1}$	WLG12-N	WLG12-N	WL-2H2100-N	
Variable rod lever 	Basic	15±5°	WLCL-N	WLCL-N	WL-1H4100-N	WL-4A100
		25±5°	WLCL-2-N	WLCL-2-N	WL-3H4100-N	
		MAX20°	WLCL-2N-N	WLCL-2N-N	WL-1H4100-N	
	High-sensitivity	10° $\pm \frac{2}{1}$	WLGL-N	WLGL-N	WL-2H4100-N	
Fork lever lock 	Basic	MAX55°	WLCA32-41-N	WLCA32-N	WL-5H5100-N	WL-5A100
			WLCA32-42-N		WL-5H5102-N	WL-5A102
			WLCA32-43-N		WL-5H5104-N	WL-5A104
			WLCA32-44-N		WL-5H5104-N	WL-5A104
Top plunger 	Basic	MAX 1.7 mm	WLD18-N	—	WL-7H100-N	—
			WLD28-N		WL-7H400-N	—
			WLD38-N		WL-7H300-N	—
Horizontal plunger 	Basic	MAX 2.8 mm	WLS2-N	—	WL-8H100-N	—
			WLS2-N		WL-8H200-N	—
			WLS3-N		WL-8H300-N	—
Flexible rod 	Basic	20±10 mm	WLNJ-N	—	WL-9H100-N	—
			WLNJ-30-N		WL-9H200-N	—
		40±20 mm	WLNJ-2-N		WL-9H300-N	—
			WLNJ-S2-N		WL-9H400-N	—

*1. The heads are not compatible with WL-series Switches.

*2. The same Actuators can be used for both WL and WL-N Switches.

Spatter-prevention Parts

Actuator	Lever Type	Item	Set	Switch without levers	Head *1 (with Actuators)	Actuator only *2
				Model	Model	Model
Roller lever 	Allen-head bolt lever	Basic	WLCA2-LES-N	WLCA2-LES-N	WL-1H1100S-N	WL-1A103S
		High-sensitivity	WLCA2-LDS-N	WLCA2-LDS-N		
	Double nut lever	Basic	WLG2-LDS-N	WLG2-LDS-N	WL-2H1100S-N	WL-1A105S
		High-sensitivity	WLG2-LDAS-N	WLG2-LDAS-N		

*1. The heads are not compatible with WL-series Switches.

*2. The same Actuators can be used for both WL and WL-N Switches.

Covers with Indicators (See Note.)

General-purpose Parts

Item	Cover	Cover only *
		Model
Neon lamp		WL-LE-N
LED		WL-LD-N

* The Covers are not compatible with WL-series Switches.

Note: The default setting is for light-ON when not operating.
Turn the lamp holder by 180° to change the setting to light-ON when operating.

Spatter-prevention Parts

Item	Cover	Cover only *
		Model
Neon lamp		WL-LES-N
LED		WL-LDS-N