

# Specifications

Photo is representative

## Eaton 192389

Eaton Moeller® series EMS2 DOL starter, 24 V DC, 1,5 - 7 (AC-53a), 9 (AC-51) A, Push in terminals, SmartWire-DT slave, Controlled stop, PTB 19 ATEX 3000

### General specifications

<b>PRODUCT NAME</b>	Eaton Moeller® series EMS2 DOL starter
<b>CATALOG NUMBER</b>	192389
<b>MODEL CODE</b>	EMS2-DOS-T-9-SWD
<b>EAN</b>	4015081930869
<b>PRODUCT LENGTH/DEPTH</b>	114.5 mm
<b>PRODUCT HEIGHT</b>	99 mm
<b>PRODUCT WIDTH</b>	22.5 mm
<b>PRODUCT WEIGHT</b>	0.297 kg
<b>CERTIFICATIONS</b>	UL508 IEC 61508 EN ISO 13849 IEC/EN 60947-4-2 UL File No.: E338590 UL Category Control No.: NLDX, NLDX7 PTB 19 ATEX 3000 UL 60947-4-1 CSA-C22.2 No. 60947-4-1- 14 CE marking UL listed Certified by UL for use in Canada UL report applies to both US and Canada

## Features & Functions

### FUNCTIONS

Controlled stop  
 Temperature compensated overload protection  
 For connecting to SmartWire-DT for expanded diagnostics  
 DOL starting  
 Motor protection  
 Automatic reset  
 Display of Device Type  
 Display of Enable signal  
 Manual reset  
 Display of Motor current in %  
 Display of Operating direction feedback  
 Operating the motor starter  
 Display of Operational readiness  
 Display of Overload prewarning  
 Display of Set short-circuit release value  
 Display of Thermal motor image in %  
 Display of Trip indications (overload, phase failure, etc.)

## Climatic environmental conditions

**AMBIENT OPERATING TEMPERATURE - MIN** -5 °C

**AMBIENT OPERATING TEMPERATURE - MAX** 55 °C

**AMBIENT STORAGE TEMPERATURE - MIN** 40 °C

**AMBIENT STORAGE TEMPERATURE - MAX** 80 °C

## General

**CLASS** CLASS 10

**CONNECTION TO SMARTWIRE-DT** Yes

**DEGREE OF PROTECTION** IP20  
NEMA Other

**MODEL** Direct starter

**MOUNTING METHOD** Top-hat rail fixing (according to IEC/EN 60715, 35 mm)  
Rail mounting possible

**MOUNTING POSITION** Motor feeder at bottom  
Vertical

**OVERLOAD RELEASE CURRENT SETTING - MIN** 1.5 A

**OVERLOAD RELEASE CURRENT SETTING - MAX** 9 A

**PRODUCT CATEGORY** Electronic motor starter

**PROTOCOL** Other bus systems

**RESIDUAL RIPPLE** ≤ 5 % (input voltage)

**TERMINAL CAPACITY** 0.2 - 2.5 mm<sup>2</sup>, Main cables, Push-in terminals

**TERMINAL CAPACITY (AWG)** 24 - 14, Push-in terminals

**TYPE** DOL starter (complete device)

**VOLTAGE TYPE** DC

## Electro magnetic compatibility

**RADIO INTERFERENCE CLASS** EN 55011  
Class A (EN 61000-6-3, emitted interference, radiated)

## Electrical rating

**INRUSH CURRENT** 120 mA (draw)

**RATED ACTUATING CURRENT (IC)** 5 mA

**RATED CONDITIONAL SHORT-CIRCUIT CURRENT (IQ), TYPE 2, 380 V, 400 V, 415 V** 0 A

**RATED CONTROL SUPPLY CURRENT IS** 60 mA

**RATED CONTROL SUPPLY VOLTAGE** 19.2 - 30 V DC

**RATED CONTROL VOLTAGE (UC)** 24 V (Actuating circuit ON, L, R)

**RATED CONTROL SUPPLY VOLTAGE (US) AT AC, 50 HZ - MIN** 0 V

**RATED CONTROL SUPPLY VOLTAGE (US) AT AC, 50 HZ - MAX** 0 V

**RATED CONTROL SUPPLY VOLTAGE (US) AT AC, 60 HZ - MIN** 0 V

**RATED CONTROL SUPPLY VOLTAGE (US) AT AC, 60 HZ - MAX** 0 V

**RATED CONTROL SUPPLY VOLTAGE (US) AT DC - MIN** 24 V

**RATED CONTROL SUPPLY VOLTAGE (US) AT DC - MAX** 24 V

**RATED OPERATIONAL CURRENT (IE)** 9 A

**RATED OPERATIONAL CURRENT (IE) AT AC-3, 380 V, 400 V, 415 V** 7 A

**RATED OPERATIONAL CURRENT (IE) AT AC-51** 9 A

**RATED OPERATIONAL CURRENT (IE) AT AC-53A - MAX** 7 A

**RATED OPERATIONAL POWER AT AC-3, 220/230 V, 50 HZ** 1.5 kW

**RATED OPERATIONAL POWER AT AC-3, 380/400 V, 50 HZ** 3 kW

## Contacts

**NUMBER OF AUXILIARY CONTACTS (NORMALLY CLOSED CONTACTS)** 0

**NUMBER OF AUXILIARY CONTACTS (NORMALLY OPEN CONTACTS)** 0

<b>RATED OPERATIONAL POWER AT AC-53A, 380/400 V, 50 HZ</b>	3 kW
<b>RATED OPERATIONAL VOLTAGE</b>	42 - 550 V 500 V AC
<b>SWITCHING LEVEL</b>	19.2 - 30 V DC, Switching level "High", Actuating circuit (ON, L, R) < 5 V DC, Switching level "confirm Off", Actuating circuit (ON, L, R) -3 - 9.6 V DC, Switching level "Low", Actuating circuit (ON, L, R)

Safety	
<b>EXPLOSION SAFETY CATEGORY FOR DUST</b>	ATEX dust-ex-protection, II (2) G [Ex e] [Ex d] [Ex px] ATEX dust-ex-protection, II (2) D [Ex t] [Ex p]
<b>SAFETY PARAMETER (EN ISO 13849-1)</b>	3, Category PL e, Performance level 60 (safe switch off) / 82 (motor protection) years; MTTFD
<b>SAFETY PARAMETER (IEC 62061)</b>	Opening delay [ms]: 200 (safe switch off) / Class 10A (motor protection) 99 % (safe switch off) / 98 % (motor protection), DC

Design verification	
<b>EQUIPMENT HEAT DISSIPATION, CURRENT-DEPENDENT PVID</b>	12 W
<b>HEAT DISSIPATION CAPACITY PDISS</b>	0 W
<b>HEAT DISSIPATION PER POLE, CURRENT-DEPENDENT PVID</b>	0 W
<b>RATED OPERATIONAL CURRENT FOR SPECIFIED HEAT DISSIPATION (IN)</b>	9 A
<b>STATIC HEAT DISSIPATION, NON-CURRENT-DEPENDENT PVS</b>	2 W
<b>HEAT DISSIPATION DETAILS</b>	If necessary, Allow for derating
<b>10.2.2 CORROSION RESISTANCE</b>	Meets the product standard's requirements.
<b>10.2.3.1 VERIFICATION OF THERMAL STABILITY OF ENCLOSURES</b>	Meets the product standard's requirements.
<b>10.2.3.2 VERIFICATION OF RESISTANCE OF INSULATING MATERIALS TO NORMAL HEAT</b>	Meets the product standard's requirements.
<b>10.2.3.3 RESIST. OF INSUL. MAT. TO ABNORMAL HEAT/FIRE BY INTERNAL ELECT. EFFECTS</b>	Meets the product standard's requirements.
<b>10.2.4 RESISTANCE TO ULTRA-VIOLET (UV)</b>	Meets the product standard's requirements.

<b>RADIATION</b>	
<b>10.2.5 LIFTING</b>	Does not apply, since the entire switchgear needs to be evaluated.
<b>10.2.6 MECHANICAL IMPACT</b>	Does not apply, since the entire switchgear needs to be evaluated.
<b>10.2.7 INSCRIPTIONS</b>	Meets the product standard's requirements.
<b>10.3 DEGREE OF PROTECTION OF ASSEMBLIES</b>	Does not apply, since the entire switchgear needs to be evaluated.
<b>10.4 CLEARANCES AND CREEPAGE DISTANCES</b>	Meets the product standard's requirements.
<b>10.5 PROTECTION AGAINST ELECTRIC SHOCK</b>	Does not apply, since the entire switchgear needs to be evaluated.
<b>10.6 INCORPORATION OF SWITCHING DEVICES AND COMPONENTS</b>	Does not apply, since the entire switchgear needs to be evaluated.
<b>10.7 INTERNAL ELECTRICAL CIRCUITS AND CONNECTIONS</b>	Is the panel builder's responsibility.
<b>10.8 CONNECTIONS FOR EXTERNAL CONDUCTORS</b>	Is the panel builder's responsibility.
<b>10.9.2 POWER-FREQUENCY ELECTRIC STRENGTH</b>	Is the panel builder's responsibility.
<b>10.9.3 IMPULSE WITHSTAND VOLTAGE</b>	Is the panel builder's responsibility.
<b>10.9.4 TESTING OF ENCLOSURES MADE OF INSULATING MATERIAL</b>	Is the panel builder's responsibility.
<b>10.10 TEMPERATURE RISE</b>	The panel builder is responsible for the temperature rise calculation. Eaton will provide heat dissipation data for the devices.
<b>10.11 SHORT-CIRCUIT RATING</b>	Is the panel builder's responsibility. The specifications for the switchgear must be observed.
<b>10.12 ELECTROMAGNETIC COMPATIBILITY</b>	Is the panel builder's responsibility. The specifications for the switchgear must be observed.
<b>10.13 MECHANICAL</b>	The device meets the

---

**FUNCTION**

requirements, provided the information in the instruction leaflet (IL) is observed.

---

## Resources

<b>APPLICATION NOTES</b>	<a href="#">eaton-motor-starter-ems2-setting-motor-protection-twincat3-ap034001-en-us.pdf</a>
<b>BROCHURES</b>	<a href="#">eaton-ems2-electronic-motorstarter-brochure-br034001en-en-us.pdf</a>
<b>CHARACTERISTIC CURVE</b>	<a href="#">eaton-contactors-ems2-reversing-starter-characteristic-curve-002.eps</a>
	<a href="#">eaton-contactors-ems2-reversing-starter-characteristic-curve-003.eps</a>
	<a href="#">eaton-contactors-ems2-reversing-starter-characteristic-curve.eps</a>
<b>DECLARATIONS OF CONFORMITY</b>	<a href="#">DA-DC-00004949.pdf</a> <a href="#">DA-DC-00004946.pdf</a> <a href="#">DA-DC-00004126.pdf</a>
<b>DRAWINGS</b>	<a href="#">eaton-contactors-ems2-reversing-starter-dimensions.eps</a> <a href="#">eaton-contactors-ems2-reversing-starter-3d-drawing.eps</a>
<b>ECAD MODEL</b>	<a href="#">DA-CE-ETN.EMS2-DOS-T-9-SWD</a>
<b>INSTALLATION INSTRUCTIONS</b>	<a href="#">eaton-ems2-electronic-motor-starter-ems2-with-swd-instruction-leaflet-il120010ZU.pdf</a>
<b>INSTALLATION VIDEOS</b>	<a href="#">Eaton's electronic motor starter EMS2</a>
<b>MANUALS AND USER GUIDES</b>	<a href="#">eaton-electronic-motor-starter-ems2-swd-manual-mn120008en-us.pdf</a>
<b>MCAD MODEL</b>	<a href="#">DA-CS-ems2_dos_ros_t_swd</a> <a href="#">DA-CD-ems2_dos_ros_t_swd</a>
<b>SALES NOTES</b>	<a href="#">eaton-rmq-chemical-resistance-flyer-fl047011en-en-us.pdf</a>

---

[eaton-ems2-electronic-  
motorstarter-flyer-  
fl034007en-en-us.pdf](#)

---

---

**PROJECT NAME:**

**PROJECT NUMBER:**

---

**PREPARED BY:**

---

**DATE:**

---



**Eaton Corporation plc**

Eaton House  
30 Pembroke Road  
Dublin 4, Ireland  
Eaton.com

© 2025 Eaton. All Rights Reserved.

Follow us on social media to get the latest product and support information.

