

PRODUCT-DETAILS

## CR-U2SM

## CR-U2SM Socket small for 2c/o CR-U relay



General Information	
Extended Product Type	CR-U2SM
Product ID	1SVR405670R1100
EAN	4013614529306
Catalog Description	CR-U2SM Socket small for 2c/o CR-U relay
Long Description	The CR-U2SM socket is from the CR-U (universal) relay range. The small socket is suitable for CR-U relays with 2 c/o (SPDT) output contacts. The socket has screw connection terminals. Pluggable function modules, holder and marker are available as accessories

Ordering	
Minimum Order Quantity	10 piece
Customs Tariff Number	85369010

Popular Downloads	
Data Sheet, Technical Information	2CDC110004C0210_05
Instructions and Manuals	1SVC405650M9000

Dimensions	
Product Net Width	38 mm

Product Net Height	24.2 mm
Product Net Depth / Length	68.2 mm
Product Net Weight	0.054 kg

Technical	
Function	Accessory for interface relays CR-U
Sub-Function	Socket for universal relays
Sub-Function 2	Socket small for universal relay 2 c/o
Output	none
Terminal Type	Screw Terminals

Environmental	
RoHS Status	Following EU Directive 2011/65/EU

Certificates and Declarations (Document Number)	
CSA Certificate	CSA_262671_2785566
cURus Certificate	cURus508_E244328
Declaration of Conformity - CE	1SVD982020-0001
Declaration of Conformity - UKCA	1SVD982020-1000
EAC Certificate	EAC_RU_C-DE.ME77.B.00446-19
Environmental Information	1SAA981009-2401
Instructions and Manuals	1SVC405650M9000
RoHS Information	1SVD982020-0001

Container Information	
Package Level 1 Units	box 10 piece
Package Level 1 Width	73 mm
Package Level 1 Height	84 mm
Package Level 1 Depth / Length	120 mm
Package Level 1 Gross Weight	0.59 kg
Package Level 1 EAN	4013614378881

Classifications	
Object Classification Code	К
ETIM 4	EC001456 - Relay socket
ETIM 5	EC001456 - Relay socket
ETIM 6	EC001456 - Relay socket
ETIM 7	EC001456 - Relay socket
ETIM 8	EC001456 - Relay socket
eClass	V11.0 : 27371603
UNSPSC	39122335

CR-U2SM 3

## Categories

 $Low\ Voltage\ Products\ and\ Systems\ \rightarrow\ Control\ Products\ \rightarrow\ Electronic\ Relays\ and\ Controls\ \rightarrow\ Interface\ Relays\ and\ Optocouplers$ 

