## **SIEMENS**

## Data sheet

## 3RA2125-4AH26-0FB4

	Load feeder fuseless, Direct-on-line starting 400 V AC, Size S0 10.016.0 A 24 V DC Spring-type terminal for 60 mm busbar systems (also fulfills type of coordination 1) Type of coordination 2, Iq = 150 kA 1 NO+1 NC (contactor) with diode combination plugged in at the front
product brand name	SIRIUS
product designation	Direct (on-line) starter
design of the product	for 60 mm busbars
product type designation	3RA21
manufacturer's article number	
<ul> <li>of the supplied contactor</li> </ul>	<u>3RT2026-2FB40</u>
<ul> <li>of the supplied circuit-breakers</li> </ul>	3RV2021-4AA25
<ul> <li>of the supplied busbar adapter</li> </ul>	<u>8US1251-5NT11</u>
<ul> <li>of the supplied link module</li> </ul>	3RA2921-2AA00
General technical data	
size of the circuit-breaker	S0
size of load feeder	SO
power loss [W] for rated value of the current	
at AC in hot operating state per pole	5 W
without load current share typical	5.9 W
insulation voltage with degree of pollution 3 at AC rated value	690 V
surge voltage resistance rated value	6 kV
degree of protection NEMA rating	other
shock resistance according to IEC 60068-2-27	6g / 11 ms
mechanical service life (operating cycles) of contactor typical	10 000 000
type of assignment	2
type of protection according to ATEX directive 2014/34/EU	Ex II (2) GD
certificate of suitability according to ATEX directive 2014/34/EU	DMT 02 ATEX F 001
reference code according to IEC 81346-2:2019	Q
Ambient conditions	
ambient temperature	
during operation	-20 +60 °C
during storage	-50 +80 °C
during transport	-50 +80 °C
temperature compensation	-20 +60 °C
relative humidity during operation	10 95 %
Main circuit	
number of poles for main current circuit	3
design of the switching contact	electromechanical
adjustable current response value current of the current- dependent overload release	10 16 A
operating voltage	
rated value	690 V
• at AC-3 rated value maximum	690 V
<ul> <li>at AC-3e rated value maximum</li> </ul>	690 V
operating frequency rated value	50 60 Hz
operational current	
<ul><li>at AC-3 at 400 V rated value</li></ul>	16 A
• at AC-3e at 400 V rated value	16 A
operating power	
• at AC-3	
— at 400 V rated value	7 500 W
• at AC-3e	
— at 400 V rated value	7 500 kW
Control circuit/ Control	

type of voltage of the control supply voltage	DC
control supply voltage at DC	
rated value	24 V
rated value	24 24 V
holding power of magnet coil at DC	5.9 W
Auxiliary circuit	
product extension auxiliary switch	Yes
number of NC contacts for auxiliary contacts	1
number of NO contacts for auxiliary contacts	1
Protective and monitoring functions	
trip class	CLASS 10
design of the overload release	thermal (bimetallic)
response value current of instantaneous short-circuit trip unit	208 A
UL/CSA ratings	
full-load current (FLA) for 3-phase AC motor	
• at 480 V rated value	16 A
at 600 V rated value	16 A
yielded mechanical performance [hp]	
<ul> <li>for single-phase AC motor</li> </ul>	
— at 110/120 V rated value	1 hp
— at 230 V rated value	2 hp
<ul> <li>for 3-phase AC motor</li> </ul>	
— at 200/208 V rated value	5 hp
<ul> <li>— at 220/230 V rated value</li> </ul>	5 hp
<ul> <li>— at 460/480 V rated value</li> </ul>	10 hp
Short-circuit protection	
product function short circuit protection	Yes
design of the short-circuit trip	magnetic
conditional short-circuit current (Iq)	
<ul> <li>at 400 V according to IEC 60947-4-1 rated value</li> </ul>	150 000 A
Installation/ mounting/ dimensions	
installation/ mounting/ unitensions	
mounting position	vertical
	vertical for snapping onto 60 mm busbar systems
mounting position	
mounting position fastening method	for snapping onto 60 mm busbar systems
mounting position fastening method height	for snapping onto 60 mm busbar systems 260 mm
mounting position fastening method height width	for snapping onto 60 mm busbar systems 260 mm 45 mm
mounting position fastening method height width depth	for snapping onto 60 mm busbar systems 260 mm 45 mm
mounting position fastening method height width depth required spacing	for snapping onto 60 mm busbar systems 260 mm 45 mm
mounting position fastening method height width depth required spacing • for grounded parts	for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards	for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm
mounting position fastening method height width depth required spacing  • for grounded parts — forwards — backwards	for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm 20 mm 0 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards	for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side	for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 20 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards	for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 20 mm
mounting position fastening method height width depth required spacing  • for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards  • for live parts	for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 20 mm 10 mm
mounting position fastening method height width depth required spacing  • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards	for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 20 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — backwards	for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 20 mm 10 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — upwards — upwards — upwards — upwards	for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 10 mm 10 mm  20 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — downwards • for live parts — forwards — backwards — backwards — upwards — downwards	for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 10 mm  20 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — at the side — downwards • for live parts — forwards — backwards — backwards — backwards — upwards — downwards — at the side	for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 10 mm  20 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — at the side — downwards • for live parts — forwards — backwards — backwards — upwards — at the side Connections/ Terminals	for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 10 mm  20 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side Connections/ Terminals type of electrical connection	for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 10 mm  20 mm 10 mm 0 mm 50 mm 20 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — to rive parts — forwards — backwards — upwards — at the side Connections/ Terminals  type of electrical connection • for main current circuit	for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 20 mm 10 mm  20 mm 0 mm 50 mm 20 mm 0 mm 50 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — to rive parts — forwards — backwards — upwards — at the side Connections/ Terminals  type of electrical connection • for main current circuit • for auxiliary and control circuit	for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 20 mm 10 mm  20 mm 0 mm 50 mm 20 mm 0 mm 50 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side — downwards — backwards — backwards — upwards — at the side Connections/ Terminals  type of electrical connection • for main current circuit • for auxiliary and control circuit Safety related data	for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 10 mm 20 mm 10 mm 50 mm 50 mm spring-loaded terminals spring-loaded terminals
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side Connections/ Terminals  type of electrical connection • for main current circuit • for auxiliary and control circuit  Safety related data touch protection on the front according to IEC 60529	for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 10 mm 20 mm 10 mm 50 mm 50 mm spring-loaded terminals spring-loaded terminals
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — backwards — upwards — touch grats — for wards — at the side Connections/ Terminals  type of electrical connection • for main current circuit • for auxiliary and control circuit  Safety related data touch protection on the front according to IEC 60529 Communication/ Protocol	for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 10 mm 20 mm 10 mm 50 mm 50 mm spring-loaded terminals spring-loaded terminals
mounting position fastening method height width depth required spacing  • for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards  • for live parts  — forwards  — backwards  — upwards  — at he side  — downwards  — to remain current circuit  • for auxiliary and control circuit  Safety related data touch protection on the front according to IEC 60529  Communication/ Protocol  protocol is supported  • PROFINET IO protocol	for snapping onto 60 mm busbar systems  260 mm  45 mm  165 mm  20 mm  0 mm  50 mm  10 mm  20 mm  10 mm  so mm  so mm  so mm  fo
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — backwards — upwards — to hackwards — at the side Connections/ Terminals  type of electrical connection • for main current circuit • for auxiliary and control circuit  Safety related data touch protection on the front according to IEC 60529 Communication/ Protocol protocol is supported	for snapping onto 60 mm busbar systems  260 mm  45 mm  165 mm  20 mm  0 mm  50 mm  10 mm  20 mm  10 mm  20 mm  somm  10 mm  somm  somm  for mm  No  No

Certificates/ approvals

**General Product Approval** 

For use in hazardous locations

**Declaration of Conformity** 

Confirmation











**Test Certificates** 

Marine / Shipping

Special Test Certificate

Type Test Certificates/Test Report











Marine / Shipping

other

Railway

**Dangerous Good** 







Confirmation

Vibration and Shock

**Transport Information** 

## **Further information**

Siemens has decided to exit the Russian market (see here).

https://press.siemens.com/global/en/pressrelease/siemens-wind-down-russian-business

Siemens is working on the renewal of the current EAC certificates.

Please contact your local Siemens office on the status of validity of the EAC certification if you intend to import or offer to supply these products to an EAC relevant market (other than the sanctioned EAEU member states Russia or Belarus).

Information on the packaging

https://support.industry.siemens.com/cs/ww/en/view/109813875

Information- and Downloadcenter (Catalogs, Brochures,...)

https://www.siemens.com/ic10

Industry Mall (Online ordering system)

https://mall.industry.siemens.com/mall/en/en/Catalog/product?mlfb=3RA2125-4AH26-0FB4

Cax online generator

http://support.automation.siemens.com/WW/CAXorder/default.aspx?lang=en&mlfb=3RA2125-4AH26-0FB4

Service&Support (Manuals, Certificates, Characteristics, FAQs,...)

https://support.industry.siemens.com/cs/ww/en/ps/3RA2125-4AH26-0FB4

Image database (product images, 2D dimension drawings, 3D models, device circuit diagrams, EPLAN macros, ...)


http://www.automation.siemens.com/bilddb/cax\_de.aspx?mlfb=3RA2125-4AH26-0FB4&lang=en

Characteristic: Tripping characteristics, I²t, Let-through current

https://support.industry.siemens.com/cs/ww/en/ps/3RA2125-4AH26-0FB4/char

Further characteristics (e.g. electrical endurance, switching frequency)

http://www.automation.siemens.com/bilddb/index.aspx?view=Search&mlfb=3RA2125-4AH26-0FB4&objecttype=14&gridview=view1



last modified: 4/18/2023 🖸