## SIEMENS

## Data sheet

## 3RA2210-0CH15-2BB4



Load feeder fuseless, Reversing duty 400 V AC, Size S00 0.18...0.25 A 24 V DC Spring-type terminal for 60 mm busbar systems (also fulfills type of coordination 1) Type of coordination 2, Iq = 150 kA 1 NC (contactor)

0 0 0 0	
product brand name	SIRIUS
product designation	Reversing starter
design of the product	for 60 mm busbars
product type designation	3RA22
manufacturer's article number	
<ul> <li>of the supplied contactor</li> </ul>	<u>3RT2015-2BB42</u>
<ul> <li>of the supplied circuit-breakers</li> </ul>	<u>3RV2011-0CA20</u>
<ul> <li>of the supplied RS assembly kit</li> </ul>	<u>3RA2913-1DB2</u>
<ul> <li>of the supplied link module</li> </ul>	<u>3RA2911-2AA00</u>
General technical data	
size of the circuit-breaker	S00
size of load feeder	S00
power loss [W] for rated value of the current	
<ul> <li>at AC in hot operating state per pole</li> </ul>	2 W
<ul> <li>without load current share typical</li> </ul>	4 W
insulation voltage with degree of pollution 3 at AC rated value	690 V
surge voltage resistance rated value	6 kV
degree of protection NEMA rating	other
shock resistance according to IEC 60068-2-27	6g / 11 ms
mechanical service life (operating cycles) of contactor typical	30 000 000
type of assignment	2
type of protection according to ATEX directive 2014/34/EU	Ex II (2) GD
certificate of suitability according to ATEX directive 2014/34/EU	DMT 02 ATEX F 001
reference code according to IEC 81346-2:2019	Q
Substance Prohibitance (Date)	10/01/2009
Ambient conditions	
ambient temperature	
during operation	-20 +60 °C
during storage	-50 +80 °C
during transport	-50 +80 °C
temperature compensation	-20 +60 °C
relative humidity during operation	10 95 %
Main circuit	
number of poles for main current circuit	3
design of the switching contact	electromechanical
adjustable current response value current of the current- dependent overload release	0.18 0.25 A
operating voltage	
<ul> <li>rated value</li> </ul>	690 V
<ul> <li>at AC-3 rated value maximum</li> </ul>	690 V

<ul> <li>at AC-3e rated value maximum</li> </ul>	690 V
operating frequency rated value	50 60 Hz
operational current	
<ul> <li>at AC-3 at 400 V rated value</li> </ul>	0.25 A
• at AC-3e at 400 V rated value	0.25 A
operating power	
● at AC-3	
— at 400 V rated value	60 W
• at AC-3e	
— at 400 V rated value	60 kW
Control circuit/ Control	
type of voltage of the control supply voltage	DC
control supply voltage at DC	50
rated value	24 V
rated value	24 v 24 24 V
holding power of magnet coil at DC	4 W
Auxiliary circuit	
product extension auxiliary switch	Yes
Protective and monitoring functions	
trip class	CLASS 10
design of the overload release	thermal (bimetallic)
response value current of instantaneous short-circuit trip unit	3.3 A
UL/CSA ratings	
full-load current (FLA) for 3-phase AC motor	
• at 480 V rated value	0.25 A
• at 600 V rated value	0.25 A
Short-circuit protection	
product function short circuit protection	Yes
design of the short-circuit trip	magnetic
conditional short-circuit current (Iq)	
• at 400 V according to IEC 60947-4-1 rated value	150 000 A
Installation/ mounting/ dimensions	
Installation/ mounting/ dimensions	vertical
mounting position	vertical
mounting position fastening method	for snapping onto 60 mm busbar systems
mounting position fastening method height	for snapping onto 60 mm busbar systems 260 mm
mounting position fastening method height width	for snapping onto 60 mm busbar systems 260 mm 90 mm
mounting position fastening method height width depth	for snapping onto 60 mm busbar systems 260 mm
mounting position fastening method height width depth required spacing	for snapping onto 60 mm busbar systems 260 mm 90 mm
mounting position fastening method height width depth required spacing • for grounded parts	for snapping onto 60 mm busbar systems 260 mm 90 mm 155 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards	for snapping onto 60 mm busbar systems 260 mm 90 mm 155 mm 32 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards	for snapping onto 60 mm busbar systems 260 mm 90 mm 155 mm 32 mm 0 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards	for snapping onto 60 mm busbar systems 260 mm 90 mm 155 mm 32 mm 0 mm 50 mm
mounting position         fastening method         height         width         depth         required spacing         • for grounded parts         — forwards         — backwards         — upwards         — at the side	for snapping onto 60 mm busbar systems 260 mm 90 mm 155 mm 32 mm 0 mm 50 mm 10 mm
mounting position         fastening method         height         width         depth         required spacing         • for grounded parts         — forwards         — backwards         — upwards         — at the side         — downwards	for snapping onto 60 mm busbar systems 260 mm 90 mm 155 mm 32 mm 0 mm 50 mm
mounting position         fastening method         height         width         depth         required spacing         • for grounded parts         — forwards         — backwards         — upwards         — at the side         — downwards         • for live parts	for snapping onto 60 mm busbar systems 260 mm 90 mm 155 mm 32 mm 0 mm 50 mm 10 mm 10 mm
mounting position         fastening method         height         width         depth         required spacing         • for grounded parts         — forwards         — backwards         — upwards         — at the side         — downwards         • for live parts         — forwards	for snapping onto 60 mm busbar systems 260 mm 90 mm 155 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm
mounting position         fastening method         height         width         depth         required spacing         • for grounded parts         — forwards         — backwards         — upwards         — at the side         — downwards         • for live parts	for snapping onto 60 mm busbar systems 260 mm 90 mm 155 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm
mounting position         fastening method         height         width         depth         required spacing         • for grounded parts         — forwards         — backwards         — upwards         — at the side         — downwards         • for live parts         — forwards         — upwards         • for live parts         — upwards         — upwards         • upwards         — upwards	for snapping onto 60 mm busbar systems 260 mm 90 mm 155 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm 50 mm 50 mm
mounting position         fastening method         height         width         depth         required spacing         • for grounded parts         — forwards         — backwards         — upwards         — at the side         — downwards         • for live parts         — forwards         — backwards         • for live parts         — backwards         — backwards	for snapping onto 60 mm busbar systems 260 mm 90 mm 155 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm
mounting position         fastening method         height         width         depth         required spacing         • for grounded parts         — forwards         — backwards         — upwards         — at the side         — downwards         • for live parts         — forwards         — upwards         • for live parts         — upwards         — upwards         • upwards         — upwards	for snapping onto 60 mm busbar systems 260 mm 90 mm 155 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm 50 mm 50 mm
mounting position         fastening method         height         width         depth         required spacing         • for grounded parts         — forwards         — backwards         — upwards         — at the side         — downwards         • for live parts         — forwards         — downwards         — obackwards         — downwards         — downwards         — downwards         — downwards         — obackwards         — downwards         — downwards         — backwards         — upwards         — downwards	for snapping onto 60 mm busbar systems 260 mm 90 mm 155 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 10 mm 10 mm 10 mm 10 mm 10 mm
mounting position         fastening method         height         width         depth         required spacing         • for grounded parts         — forwards         — backwards         — upwards         — at the side         — forwards         • for live parts         — forwards         — backwards         — ownwards         • for live parts         — forwards         — backwards         — upwards         — at the side         — upwards         — at the side	for snapping onto 60 mm busbar systems 260 mm 90 mm 155 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 10 mm 10 mm 10 mm 10 mm 10 mm
mounting position         fastening method         height         width         depth         required spacing         • for grounded parts         — forwards         — backwards         — upwards         — at the side         — downwards         • for live parts         — forwards         — backwards         — downwards         • for live parts         — forwards         — backwards         — the side         — downwards         — the side         — downwards         — at the side	for snapping onto 60 mm busbar systems 260 mm 90 mm 155 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 10 mm 10 mm 10 mm 10 mm 10 mm
mounting position         fastening method         height         width         depth         required spacing         • for grounded parts         — forwards         — backwards         — upwards         — at the side         — downwards         • for live parts         — forwards         — backwards         — at the side         — downwards         • for live parts         — forwards         — backwards         — at the side         — backwards         — upwards         — backwards         — upwards         — at the side         Connections/ Terminals         type of electrical connection	for snapping onto 60 mm busbar systems 260 mm 90 mm 155 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 10 mm 10 mm 10 mm 10 mm 10 mm 10 mm
mounting position         fastening method         height         width         depth         required spacing         • for grounded parts         — forwards         — backwards         — upwards         — at the side         — downwards         • for live parts         — forwards         — backwards         — upwards         — forwards         — forwards         — at the side         — downwards         — forwards         — at the side         — downwards         — backwards         — upwards         — at the side         Connections/ Terminals         type of electrical connection         • for main current circuit	for snapping onto 60 mm busbar systems 260 mm 90 mm 155 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 50 mm 10 mm 10 mm 50 mm 10 mm 50 mm 10 mm 50 mm 10 mm
mounting position         fastening method         height         width         depth         required spacing         • for grounded parts         — forwards         — backwards         — upwards         — at the side         — downwards         • for live parts         — forwards         — backwards         — upwards         — forwards         — downwards         • for live parts         — forwards         — backwards         — upwards         — downwards         — odownwards         — of orwards         — for runnals         type of electrical connection         • for main current circuit         • for auxiliary and control circuit         Safety related data	for snapping onto 60 mm busbar systems 260 mm 90 mm 155 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 50 mm 10 mm 10 mm 50 mm 10 mm 50 mm 10 mm 50 mm 10 mm
mounting position         fastening method         height         width         depth         required spacing         • for grounded parts         — forwards         — backwards         — upwards         — at the side         — downwards         • for live parts         — forwards         — backwards         — upwards         — forwards         — downwards         — backwards         — upwards         — downwards         — forwards         — forwards         — backwards         — upwards         — downwards         — at the side         Connections/ Terminals         type of electrical connection         • for main current circuit         • for auxiliary and control circuit         Safety related data         B10 value with high demand rate according to SN 31920	for snapping onto 60 mm busbar systems 260 mm 90 mm 155 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm 50 mm 10 mm 10 mm 50 mm 10 mm 50 mm 10 mm 50 mm 10 mm 50 mm
mounting position         fastening method         height         width         depth         required spacing         • for grounded parts         — forwards         — backwards         — upwards         — at the side         — downwards         • for live parts         — forwards         — backwards         — upwards         — for nurds         — for authe side         Connections/Terminals         type of electrical connection         • for main current circuit         • for auxiliary and control circuit         Safety related data         B10 value with high demand rate according to SN 31920         proportion of dangerous failures	for snapping onto 60 mm busbar systems 260 mm 90 mm 155 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm 50 mm 10 mm 10 mm 50 mm 10 mm 50 mm 10 mm 50 mm 10 mm 50 mm
mounting position         fastening method         height         width         depth         required spacing         • for grounded parts         — forwards         — backwards         — upwards         — at the side         — downwards         • for live parts         — forwards         — backwards         — upwards         — forwards         — backwards         — downwards         • for live parts         — forwards         — backwards         — upwards         — backwards         — backwards         — upwards         — downwards         — at the side         Connections/ Terminals         type of electrical connection         • for auxiliary and control circuit         • for auxiliary and control circuit         Safety related data         B10 value with high demand rate according to SN 31920         proportion of dangerous failures         • with high demand rate according to SN 31920	for snapping onto 60 mm busbar systems 260 mm 90 mm 155 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm 50 mm 10 0000 10 000
mounting position         fastening method         height         width         depth         required spacing         • for grounded parts         — forwards         — backwards         — upwards         — at the side         — downwards         • for live parts         — forwards         — backwards         — upwards         — for nurds         — for authe side         Connections/Terminals         type of electrical connection         • for main current circuit         • for auxiliary and control circuit         Safety related data         B10 value with high demand rate according to SN 31920         proportion of dangerous failures	for snapping onto 60 mm busbar systems 260 mm 90 mm 155 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm 50 mm 10 mm

protocol is supported					
<ul> <li>PROFINET IO pr</li> </ul>	rotocol	No			
<ul> <li>PROFIsafe proto</li> </ul>	col	No			
protocol is supported A	S-Interface protocol	No			
Certificates/ approvals					
General Product App	roval		For use in hazard- ous locations	Declaration of Confo	rmity
<u>Confirmation</u>	(UL)	EHC	K ATEX	CE EG-Konf.	UK CA
Test Certificates		Marine / Shipping			
Type Test Certific- ates/Test Report	Special Test Certific- ate	ABS	BUREAU VERITAS	Lloyd's Register Lits	PRS
Marine / Shipping			other	Railway	Dangerous Good
RINA	KARS	DNV-GL DIVI-GL	<u>Confirmation</u>	Vibration and Shock	Transport Information

## Further information

Siemens has decided to exit the Russian market (see here).

https://press.siemens.com/global/en/pressrelease/siemens-wind-down-russian-business

Siemens is working on the renewal of the current EAC certificates.

Please contact your local Siemens office on the status of validity of the EAC certification if you intend to import or offer to supply these products to an EAC relevant market (other than the sanctioned EAEU member states Russia or Belarus).

Information on the packaging

https://support.industry.siemens.com/cs/ww/en/view/109813875

Information- and Downloadcenter (Catalogs, Brochures,...)

https://www.siemens.com/ic10

Industry Mall (Online ordering system)

https://mall.industry.siemens.com/mall/en/en/Catalog/product?mlfb=3RA2210-0CH15-2BB4

Cax online generator

http://support.automation.siemens.com/WW/CAXorder/default.aspx?lang=en&mlfb=3RA2210-0CH15-2BB4

Service&Support (Manuals, Certificates, Characteristics, FAQs,...)

https://support.industry.siemens.com/cs/ww/en/ps/3RA2210-0CH15-2BB4

Image database (product images, 2D dimension drawings, 3D models, device circuit diagrams, EPLAN macros, ...)


http://www.automation.siemens.com/bilddb/cax\_de.aspx?mlfb=3RA2210-0CH15-2BB4&lang=en


Characteristic: Tripping characteristics, I<sup>2</sup>t, Let-through current


https://support.industry.siemens.com/cs/ww/en/ps/3RA2210-0CH15-2BB4/char


Further characteristics (e.g. electrical endurance, switching frequency)

http://www.automation.siemens.com/bilddb/index.aspx?view=Search&mlfb=3RA2210-0CH15-2BB4&objecttype=14&gridview=view1









last modified:

5/1/2023 🖸