SIEMENS

Data sheet

3RQ3065-1SM30



Output coupler Optocoupler 1 NO, Transistor, 24 V DC Output max. 30 V DC, 5 A with M-0-A switch short circuit-proof screw terminal Overall width 6.2 mm Thermal current 5A

| product brand name | SIRIUS | | |
|---|---|--|--|
| product category | SIRIUS 3RQ3 coupling relays in slim design | | |
| product designation | Coupling relays with semiconductor output (not plug-in) | | |
| design of the product | Output coupling link | | |
| product type designation | 3RQ3 | | |
| General technical data | | | |
| display version LED | Yes | | |
| product component | | | |
| relay output | No | | |
| semi-conductor output | Yes | | |
| consumed active power | 0.3 W | | |
| insulation voltage for overvoltage category III according to IEC 60664 with degree of pollution 3 rated value | 50 V | | |
| surge voltage resistance rated value | 2.5 kV | | |
| protection class IP | IP20 | | |
| flammability class of enclosure material | UL94 V-0 | | |
| shock resistance | | | |
| according to IEC 60068-2-27 | sinusoidal half-wave 15g / 11 ms | | |
| vibration resistance | | | |
| according to IEC 60068-2-6 | 6 150 Hz: 2 g | | |
| switching frequency | 100 Hz | | |
| thermal current | 5 A | | |
| reference code according to IEC 81346-2 | К | | |
| Substance Prohibitance (Date) | 03/25/2015 | | |
| Control circuit/ Control | | | |
| control supply voltage at DC | | | |
| rated value | 11 30 V | | |
| operating range factor control supply voltage rated value at DC | | | |
| • initial value | 1 | | |
| full-scale value | 1 | | |
| minimum switching voltage when switching on | 11 V | | |
| maximum switching voltage when switching off | 5 V | | |
| ON-delay time | | | |
| • at DC maximum | 0.2 ms | | |
| OFF-delay time | 0.3 ms | | |
| product component plug-in socket | No | | |
| Auxiliary circuit | | | |
| type of switching contact | NO contact | | |
| number of NO contacts for auxiliary contacts | 1 | | |
| Main circuit | | | |

| tune of voltage | |
|--|--|
| type of voltage | DC |
| Inputs/ Outputs | Vee |
| property of the output short-circuit proof | Yes |
| switching voltage of the semiconductor output at DC | 10 30 V |
| ampacity of the semiconductor output at DC | 5 mA 5 A |
| Electromagnetic compatibility | |
| EMC emitted interference according to IEC 60947-1 | ambience A (industrial sector) |
| EMC immunity according to IEC 60947-1 | corresponds to degree of severity 3 |
| conducted interference | |
| • due to burst according to IEC 61000-4-4 | 2 kV |
| • due to conductor-earth surge according to IEC 61000-4-5 | 2 kV |
| due to conductor-conductor surge according to IEC 61000-4-5 | 1 kV |
| field-based interference according to IEC 61000-4-3 | 10 V/m |
| electrostatic discharge according to IEC 61000-4-2 | 6 kV contact discharge / 8 kV air discharge |
| Display | |
| display version as status display by LED | LED green |
| Connections/ Terminals | |
| product function removable terminal | No |
| type of electrical connection for auxiliary and control circuit | screw-type terminals |
| wire length | |
| • at DC maximum | 1 000 m |
| type of connectable conductor cross-sections | |
| • solid | 1x (0.25 2.5 mm²) |
| finely stranded with core end processing | 1x (0.25 1.5 mm ²) |
| at AWG cables solid | 1 x (20 14) |
| connectable conductor cross-section | |
| • solid | 0.25 2.5 mm² |
| finely stranded with core end processing | 0.25 1.5 mm² |
| AWG number as coded connectable conductor cross | |
| section | |
| | |
| • solid | 20 14 |
| tightening torque with screw-type terminals | 20 14 0.5 0.6 N·m |
| | |
| tightening torque with screw-type terminals | |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method | 0.5 0.6 N·m |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height | 0.5 0.6 N·m any snap-on mounting 93 mm |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method | 0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth | 0.5 0.6 N·m any snap-on mounting 93 mm |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing | 0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting | 0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 75 mm |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting — forwards | 0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 75 mm 0 mm |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting — forwards — backwards | 0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 75 mm 0 mm 0 mm |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting — forwards — backwards — upwards | 0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 75 mm 0 mm 0 mm 0 mm |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting — forwards — backwards — upwards — downwards | 0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 75 mm 0 mm 0 mm 0 mm 0 mm |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side | 0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 75 mm 0 mm 0 mm 0 mm |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting forwards backwards upwards downwards at the side • for grounded parts | 0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 75 mm 0 mm |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting - forwards - backwards - upwards - downwards - at the side • for grounded parts - forwards - for | 0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 75 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting forwards backwards upwards downwards at the side • for grounded parts forwards backwards | 0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 75 mm 0 mm |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting - forwards - backwards - upwards - downwards - at the side • for grounded parts - forwards - backwards - upwards - up | 0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 75 mm 0 mm |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting - forwards - backwards - backwards - upwards - at the side • for grounded parts - forwards - backwards - backwards - at the side - | 0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 75 mm 0 mm |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting - forwards - backwards - upwards - downwards - at the side • for grounded parts - forwards - backwards - upwards - at the side - at | 0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 75 mm 0 mm |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting - forwards - backwards - backwards - upwards - downwards - at the side • for grounded parts - forwards - upwards - at the side - downwards - at the side - at the side - at the side - at the side - at the | 0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 75 mm 0 mm |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting - forwards - backwards - backwards - upwards - downwards - at the side • for grounded parts - forwards - backwards - upwards - at the side - downwards - at the side - downwards - at the side - downwards - for live parts - forwards - forwards - forwards - forwards - forwards - forwards - for live parts - forwards - for live parts - forwards - forwa | 0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 75 mm 0 mm |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts — forwards — backwards — upwards — at the side — downwards — at the side — downwards — at the side — downwards • for live parts — forwards • for live parts — forwards — backwards — backwards — downwards • for live parts — forwards — backwards — backwards • for live parts — forwards — backwards — backwards • for live parts — forwards — backwards — backwards — backwards • for live parts — forwards — backwards — backwards | 0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 75 mm 0 mm |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting - forwards - backwards - backwards - upwards - downwards - at the side • for grounded parts - forwards - backwards - upwards - at the side - downwards - at the side - downwards • for live parts - forwards • for live parts - forwards - backwards - upwards - backwards - upwards - downwards - at the side - downwards - at the side - downwards - at the side - downwards - backwards - upwards - forwards - upwards - upwar | 0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 75 mm 0 mm |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting - forwards - backwards - backwards - upwards - at the side • for grounded parts - forwards - at the side - downwards - at the side - downwards - at the side - for live parts - forwards - backwards - upwards - backwards - upwards - backwards - upwards - forwards - at the side - downwards - backwards - upwards - backwards - backwards - backwards - upwards - backwards | 0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 75 mm 0 mm |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting - forwards - backwards - upwards - downwards - at the side • for grounded parts - forwards - backwards - upwards - at the side • for live parts - forwards - backwards - upwards - backwards - backwards - backwards - downwards - forwards - downwards - at the side • for live parts - forwards - backwards - upwards - backwards - upwards - backwards - backwar | 0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 75 mm 0 mm |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting - forwards - backwards - backwards - upwards - at the side • for grounded parts - forwards - backwards - upwards - backwards - upwards - at the side • for live parts - forwards - backwards - upwards - backwards - upwards - backwards - downwards - at the side • for live parts - forwards - backwards - upwards - backwards - at the side - downwards - backwards - upwards - backwards - ba | 0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 75 mm 0 mm |
| tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • with side-by-side mounting - forwards - backwards - upwards - downwards - at the side • for grounded parts - forwards - backwards - upwards - at the side • for live parts - forwards - backwards - upwards - backwards - backwards - backwards - downwards - forwards - downwards - at the side • for live parts - forwards - backwards - upwards - backwards - upwards - backwards - backwar | 0.5 0.6 N·m any snap-on mounting 93 mm 6.2 mm 75 mm 0 mm |

| during operation | | -25 . | +60 °C | | | | | |
|--|---|-------------------|---------------------|-----|--------------------------------|--|--|--|
| during storage | | -40 . | +85 °C | | | | | |
| during transport | | -40 +85 °C | | | | | | |
| relative humidity during | operation | 10 95 % | | | | | | |
| Certificates/ approvals | | | | | | | | |
| General Product Appr | roval | | | EMC | Declaration of Con- formity | | | |
| SP EM | <u>Confirmation</u> | | EHC | RCM | UK CA | | | |
| Declaration of Con- formity | Test Certificates | Marine / Shipping | other | | | | | |
| CC EG-Konf. | <u>Type Test Certific-</u> ates/Test Report | | <u>Confirmation</u> | | | | | |
| Further information | | | | | | | | |
| Siemens has decided to exit the Russian market (see here). | | | | | | | | |
| https://press.siemens.com/global/en/pressrelease/siemens-wind-down-russian-business | | | | | | | | |
| Siemens is working on the renewal of the current EAC certificates. Please contact your local Siemens office on the status of validity of the EAC certification if you intend to import or offer to supply these products to an EAC relevant market (other than the sanctioned EAEU member states Russia or Belarus). | | | | | | | | |
| Information on the packaging https://support.industry.siemens.com/cs/ww/en/view/109813875 | | | | | | | | |
| Information- and Downloadcenter (Catalogs, Brochures,) | | | | | | | | |
| https://www.siemens.com/ic10 | | | | | | | | |
| Industry Mall (Online ordering system) https://mall.industry.siemens.com/mall/en/en/Catalog/product?mlfb=3RQ3065-1SM30 | | | | | | | | |
| Cax online generator http://support.automation.siemens.com/WW/CAXorder/default.aspx?lang=en&mlfb=3RQ3065-1SM30 | | | | | | | | |
| Service&Support (Manuals, Certificates, Characteristics, FAQs,) https://support.industry.siemens.com/cs/ww/en/ps/3RQ3065-1SM30 | | | | | | | | |
| | Image database (product images, 2D dimension drawings, 3D models, device circuit diagrams, EPLAN macros,) | | | | | | | |

Image database (product images, 2D dimension drawings, 3D models, device circuit d http://www.automation.siemens.com/bilddb/cax_de.aspx?mlfb=3RQ3065-1SM30&lang=en

Characteristic: Derating https://support.industry.siemens.com/cs/ww/en/ps/3RQ3065-1SM30/manual





last modified:

5/6/2021 🖸